



SUPPLY FAN PERFORMANCE AND MOTOR SELECTION GUIDE

(Intersect CFM with external static pressure to determine fan h.p.)

CFM	OUTLET VEL. FPM		0.5 ESP	1.0 ESP	1.5 ESP	2.0 ESP	2.5 ESP	3.0 ESP	3.5 ESP
3500	1824	RPM	1652	1754	1852	1948	2040	N/A	N/A
		BHP	2.28	2.65	3.03	3.43	3.84		
		hp	3	5	5	5	5		
3750	1954	RPM	1718	1816	1910	2001	2089	N/A	N/A
		BHP	2.6	2.99	3.39	3.8	4.23		
		hp	3	5	5	5	5		
4000	2084	RPM	1794	1886	1975	2062	N/A	N/A	N/A
		BHP	2.98	3.39	3.8	4.24			
		hp	5	5	5	5			
4250	2215	RPM	1861	1949	2034	2118	N/A	N/A	N/A
		BHP	3.37	3.79	4.22	4.67			
		hp	5	5	5	7.5			
4500	2345	RPM	1976	2058	N/A	N/A	N/A	N/A	N/A
		BHP	4.03	4.47					
		hp	5	7.5					

EXHAUST FAN PERFORMANCE AND MOTOR SELECTION GUIDE

(Intersect CFM with external static pressure to determine fan h.p.)

CFM	OUTLET VEL. FPM		0.5 ESP	1.0 ESP	1.5 ESP	2.0 ESP	2.5 ESP	3.0 ESP	3.5 ESP
3500	1824	RPM	1309	1422	1532	1638	1740	1839	1934
		BHP	1.24	1.55	1.88	2.23	2.59	2.98	3.37
		hp	1.5	2	3	3	3	5	5
3750	1954	RPM	1370	1477	1581	1682	1779	1874	1966
		BHP	1.42	1.75	2.1	2.46	2.84	3.23	3.64
		hp	2	3	3	3	5	5	5
4000	2084	RPM	1432	1533	1632	1728	1822	1913	2001
		BHP	1.63	1.97	2.33	2.71	3.1	3.51	3.93
		hp	2	3	3	5	5	5	5
4250	2215	RPM	1499	1595	1689	1781	1870	1957	2042
		BHP	1.87	2.23	2.61	3.01	3.41	3.83	4.26
		hp	3	3	5	5	5	5	5
4500	2345	RPM	1568	1659	1749	1836	1922	2006	2087
		BHP	2.14	2.52	2.92	3.32	3.75	4.18	4.63
		hp	3	3	5	5	5	5	7.5

FAN MOTOR AMP DRAW CHART

hp	208	240	480
1-1/2	4.5	4.4	2.2
2	6.0	5.9	3.0
3	8.6	8.4	4.2
5	14.0	12.7	6.4
7.5	21.0	19.0	9.5

WHEEL MOTOR AMP DRAW CHART

	208	240	480
1/4 hp	1.0	1.0	0.5

ACCESSORIES AMP DRAW CHART

	208	240	480
Enthalpy Wheel Rotation Detection	0.20	0.20	0.10
Damper Motor (ea.)	0.75	0.75	0.50
Radiant Defrost Heater Pkg. (ea.)	4.57	3.95	1.97
TRICOIL Pump Motor	2.00	2.00	1.00
Hot Water Modulating Ball-Valve	0.20	0.20	0.10
Temperature Sensor (ea.)	0.50	0.50	0.25
Lights and Receptical	12.00	12.00	6.00
Variable Frequency Drive for Fan (ea.)	0.50	0.50	0.25
Variable Frequency Drive for TRICOIL	0.25	0.25	0.15

Performance numbers are based on optimum conditions. Consult factory for precise performance.

Berner International Corp.

111 Progress Avenue, New Castle, PA 16101 / Telephone (724) 657-5301 / FAX (724) 652-0682 / www.berner.com / info@bernerenergy.com

©Copyright, 2009 Berner International Corp.